



DRYGLOVE



Operating instructions  
Diving glove assembly

[www.dryglove.com](http://www.dryglove.com)

# so simple to use

1.1



1.2



Disassemble the sleeve protective ring (MS) from your diving suit as an assembly tool and take off the o-ring from the sleeve protective ring

Pull the o-ring of the spare parts kit non-lubricated on to the largest diameter of the sleeve protective ring (MS).

2.1



2.2



2.3



Insert the sleeve protective ring (MS) with the drawn-on o-ring ahead into the latex diving glove and put the diving glove up to the groove over the o-ring in the same way.

3.1



3.2



3.3



4.1

4.2

Shift the diving glove ring (HS) of the spare parts kit with the smaller diameter over the sleeve protective ring



5.1

5.2



Put the latex diving glove together with the lower o-ring on the diving glove ring (HS).

Press the sleeve ring (MS) a little into the diving glove, turn it by 90 degrees and pull it out of the glove.

6.1

6.2

6.3



Insert the bead of the protective o-ring into the notch of the diving glove ring and pull it over the o-ring

7.1



7.2



7.3



## Cleaning

Rinse the diving gloves with water after use. Do not put the diving gloves under the sun or on heat radiators for drying

## Storage

Keep the diving glove system at a dark and cool place. Avoid exposing the diving glove system to intense solar radiation. Do not stock your diving glove system nearby any devices which produce ozone, e.g. motors, heating devices, or others

## Maintenance

The diving glove system does not require any particular maintenance. Before each use check if there are any spots on the diving gloves and on the o-rings. If there are any spots on the diving gloves or on the o-rings, replace the corresponding parts. Slightly lubricate the red o-ring. To do so, use the Dryglove grease. If any other grease which is not approved is being used this will render the warranty null and void

## Certification

The Dryglove dry diving gloves had been certified according to the EC guideline 89/686/ EEC item 10. EN 14225-2:2005, TÜV Rheinland Product Safety GmbH, Am Grauen Stein, D-51105 Köln, Notified Body 0197.

In case of any doubts regarding this instruction for operating instruction or if your shop or your instructor will not give you sufficient information, please contact:

KWTT GmbH - Hirsauer Strasse 149 - 75180 Pforzheim  
phone +49 (0) 7231 - 42 44 770 Fax: +49 (0) 7231 - 42 44 780 info@dryglove.com



[www.dryglove.com](http://www.dryglove.com)